

Setting up an iPad with the Sony Cyber-shot DSC-QX10

Many students with vision impairments are using the Sony Cybershot DXC QX10 to view the whiteboard through the iPad. This is a very compact camera which is 6 centimetres in diameter. Combined with a tripod it stands about 22 centimetres in height and can be placed unobtrusively in front of the whiteboard and wirelessly connected to the iPad. It has 10X optical zoom and 18.2 mega pixels.

To use the Sony QX10 with an iPad you need to download the PlayMemories app which is free from the iTunes store. This app then allows you to connect the camera to the iPad using Wi-Fi.

The camera allows you to zoom in and out. You have the option of photo or video mode.

Here's how to set one up:

1. Turn the power to the camera off – on/off button is on the top of the camera
2. Charge the camera using the lead provided
3. Download PlayMemories from iTunes onto the iPad
4. Turn the power to the camera on
5. Turn on the iPad
6. Go to Settings
7. Select Wi-Fi
8. Type in the password which can be found on the cover of the instruction manual or on the inside of the camera's battery cover
9. Check that the Wi-Fi has connected to the camera – indicated by a blue tick
10. Press the Home button
11. Open PlayMemories and the image will come through to the iPad

For further information, refer to the [camera's instruction manual](#):

Sony Cyber-shot DSC-QX10



Updated by Lyn Robinson, July 2015