

## Using wireless to get a visual display of the BrailleNote on the iPad

Lea Nagel 2015

### BrailleNote Setup:

1. Activate the options menu with space with o.
2. Press the letter c for the connectivity menu.
3. Press the letter w to select the wireless menu.
4. When asked if you want to turn on wireless? Press the letter y followed by enter
5. Press the letter s to scan for networks.
6. Press the space bar until your desired network is shown. Activate it by pressing enter.
7. Press space to navigate to the security key?
8. Type in the wireless security password. Remember to use drop numbers if necessary.
9. Press the main menu key or space with all 6 dots to jump to the main menu.
10. When asked if you want to add this connection? Press Y.

### BrailleNote – turning on:

Options visual display w for wireless 8" vga semi portable

### iPad Setup:

Settings, WIFI, Choose network, Security key (SVRC = Statewide.Vision0242), Join

### iPad – turning on:

1. VNC viewer (search iPad for this), press + (to add a connection)
2. From the Braille Note read the IP address displayed in braille, and enter it on the IOS device in the address field.
3. Tap next.
4. Give the connection a name, and tap next.
5. If you do not wish for the connection to be password protected, press the letter N on the braille note.

Tap connect on the IOS device, and a connection will be established.